



# ChatterBox!™

THE ORIGINAL COMMUNICATOR

**X<sup>2</sup> SLIM**  
*Communication is Key*



 Bluetooth

## Owner's Manual





# Table of Contents

- 1. GETTING STARTED .....4**
  - WHAT'S NEW? .....4
  - UNPACKING AND INSPECTION .....4
  - BATTERY .....5
  - INSTALLATION OF HEADSET, MAIN UNIT AND WIRED PTTB (PUSH TO TALK BUTTON) .....5
  
- 2. GETTING TO KNOW YOUR X2SLIM .....7**
  - BUTTONS AND INPUTS .....7
  - MULTI-FUNCTION BUTTONS .....8
  - LCD DISPLAY .....8
  - CONTROL KNOB .....8
  - SHORT PRESS CONTROL KNOB .....9
  - MULTIPLE DEVICE MODES .....9
  
- 3. BIKE TO BIKE COMMUNICATION .....10**
  - POWER ON/OFF .....10
  - SET VOLUME LEVEL .....10
  - CHOOSE A CHANNEL FOR THE GROUP .....10
  - USING THE VOICE ACTIVATION FEATURE (VOX) .....11
  
- 4. RIDER TO PASSENGER COMMUNICATION .....11**
  - LISTENING TO BIKE TO BIKE COMMUNICATION .....11
  - RIDER AND PASSENGER ONLY COMMUNICATION .....11
  
- 5. BLUETOOTH FEATURE WITH AUDIO CONTROL .....12**
  - BLUETOOTH® FEATURE .....12
  - PAIRING .....12
  - PAIRING MULTIPLE DEVICES .....12
  - USING SMARTPHONE TO GET MUSIC, PHONE, AND NAVIGATION .....13
  - REMOTE CONTROL .....14
  
- 6. FM RADIO .....14**
  - TURN ON/OFF THE FM RADIO .....14
  - CHANGE VOLUME .....14
  - SEARCH FM RADIO STATIONS .....14





# Table of Contents

<b>7. PUTTING IT ALL TOGETHER .....</b>	<b>14</b>
TYPICAL SETTING .....	14
PRIORITY .....	15
SUMMARY OF BUTTON FUNCTIONS .....	15
<b>8. ACCESSORIES.....</b>	<b>16</b>
<b>9. TROUBLE SHOOTING .....</b>	<b>17</b>
<b>10. IMPORTANT INFORMATION .....</b>	<b>17</b>
CHATTERBOX USA LIMITED WARRANTY .....	17
FCC COMPLIANCE .....	17
US MOTORCYCLE LAWS BY STATES .....	18
TECHNICAL SPECIFICATION .....	18
<b>X2SLIM WIRELESS PTT (FOR -P MODEL ONLY) .....</b>	<b>19</b>

### Caution

1. Please use this product over 2.5cm apart from one's body.
2. Do not use the product while putting this product in one's pocket.



# 1. Getting Started

## What's new?




Thank you for your recent purchase of the Chatterbox X2Slim. The X2Slim is the replacement model for our current flagship X1Slim. The X1Slim has always been favored by riders for all of its advanced features. Per your request the X2Slim is lighter and smaller with HD quality sound. The following is a detailed comparison chart that shows the new features of the X2Slim.

Features	X1Slim	X2Slim
Wireless PTT	Yes	No*
Bike to Bike two way communication among unlimited riders	Yes	Yes
22 channel with 38 talk groups for each channel	Yes	Yes
Hands free voice activation or Push to Talk capability	Yes	Yes
Rider to passenger communication capability(intercom)	Yes	Yes
Share music	Yes	Yes
Two way communication with passenger(open group talk)	Yes	No
Answer phone calls and listen to music wirelessly	Yes	Yes
True hi-fi stereo speakers and noise suppression microphones	Yes	Yes
8 hours of talk time and 20 hours of standby	Yes	Yes
Fm radio	Yes	Yes
Headset with microphones for open and full face helmets	Yes	Yes
Cradle with headset and microphone support for clean install	No	Yes
Control Knob for easier rider support	No	Yes


\* Wireless PTT applicable for X2Slim-p version.

## Unpacking and inspection

Please check and make sure that you have everything listed below inside the box. If you find any parts missing or that have been damaged, please contact our customer service immediately.

1		X2Slim Unit with Battery pre-installed
2		USB charging cable and AC adaptor
3		Multi microphone Headset which includes microphones for open and full face helmets, two Velcro speaker disks, two foam microphone covers, and microphone Velcro



4		Handle bar mount push to talk button and extension cord
5		Helmet mounting bracket with Cradle, two screws and Allen wrench

## Battery

The X2Slim comes with a rechargeable Li-ion battery pre-installed inside of the unit. Please do not attempt to open the case to replace the battery.

We recommend that the battery be pre-conditioned to restore to the original state.

- 1) Discharge the battery completely by leaving the unit on until the battery is completely drained.
- 2) Charge the battery completely using the charger supplied with the kit. It should take about 5 hours to fully charge the battery.

If you are planning to store the unit for a long period of time, store it after fully charging the battery. Upon using it again, please follow the pre-conditioning process described above.

To reduce the risk of damage to the battery, do not use any other charger except the one supplied with the kit. Make sure the battery is always stored at room temperature.

Battery indicator in the LCD display means as followed:

Indicator	Means
3 Bars	Fully Charged
2 Bars	Half Charged
1 Bar	Low Charged

When the battery indicator shows 1 bar, you need to charge the battery. Or you can hear voice prompt when it is time to charge the battery.

## Installation of headset, main unit and wired PTTB (Push to talk button)

The Multi Headset comes with both open and full face microphones. Choose the one that you intend to use and plug it into the connector on the cradle. Please keep the microphone that you are not using in a safe place for future use. All microphones come with foam cover. For full face helmet, attach soft Velcro disk to the helmet chin bar and hard Velcro disk to the microphones.




The headset speakers should already have Velcro on the back casing. Simply apply the soft Velcro disks on the liner of your helmet. Mount them in the indentation of the helmet padding where your ears would line up. Please keep in mind that you need to mount the speakers in a location that is directly next to your ears.






Attach the right speaker (with the longer wire) to the corresponding Velcro disk that you applied on the helmet liner. Attach the left speaker (with the shorter wire) to the other Velcro disk. For helmets with speaker pockets, simply insert the speakers in each corresponding pocket. If your helmet has washable lining that pops out, you can tuck the wires behind that.



Fasten the mounting bracket snugly to the bottom left side of the helmet with two bolts supplied. Align the back side of the X2Slim unit to the grooves on the mounting bracket. Slide the X2Slim unit down on the mounting bracket until it latches firmly into place.



Insert the 3.5mm plug of the headset into the Rider's headset jack on the bottom of the cradle.




If you decide to use the handle bar mount PTT button, place the wired PTT button on the left side handle bar grip (closest to where your thumb would be) of the motorcycle using the integrated Velcro strip. And insert the 2.5mm plug into the PTT input in the back of the manual unit.



## 2. Getting to know your X2Slim

### Buttons and inputs

The X2Slim is packed with many features in a light compact casing. Please refer to the picture shown below to find out the location and functions of each button.



	Buttons & Inputs	Description
		These are brief descriptions of the buttons and inputs. Detailed descriptions and specific instructions will be provided later in the manual
1	Power Button	• Turns unit on and off
2	PTT (push to talk) Button	• Transmit to other riders or your passenger • Complete settings
3	LCD Display Window	• Displays unit information
4	Microphone (Cradle)	• Microphone input for rider
5	Rider Headset Jack	• Headset input for rider
6	Control Knob	• Access different mode functions • Answer and end phone calls • Adjust settings within modes • Volume up/down • Forward and rewind tracks
7	Charger	• Wall charger port
8	Passenger Ear Jack	• Input for passenger headset
9	PTT Input	• Wired push to talk button input
10	LED Window	• Represents Bluetooth® pairing

## Multi-function buttons

The Control Knob handles more than one function. These are the 3 ways to use the Control Knob.

Long press	Press the button and hold it for 3 seconds
Double press	Press twice
Short press	Press the button for half second

## LCD display

The X2Slim is equipped with an LCD display that shows the status of the X2Slim. The table below shows the icons and what they mean.



	Description	Appears when:
	Sensitivity	Shows the strength of the incoming signal.
	Bluetooth®	Unit is paired to a Bluetooth® device.
	Sound	Unit is set to music playing mode.
<b>FM</b>	FM Radio Mode	Unit is set to FM radio mode.
<b> </b>	Intercom	Unit is set to Intercom mode.
	Battery Meter	Indicates status of battery power.
<b>VOX</b>	VOX	Hands free communication is active.
<b>CTS</b>	Talk Group Type	Indicates that the sub-channel is in use.
<b>SCN</b>	Wireless PTT*	Unit is paired to a Wireless PTT.
<b>88</b>	Talk group	Indicates talking group number.
<b>188</b>	Channel	Indicates channel number.

\* Wireless PTT applicable for X2Slim-p version.

## Control Knob

The Control Knob is used to choose the desired function setting. The table below shows the different settings that you can use along with a brief description.

Common Fuction (Perform in every mode)

- To enter each mode: Press Control Knob twice, and then turn Control Knob.  
(An order of switching mode: COM -> INT -> FM -> MP -> COM ->)
- To enter the selected mode, press the Control Knob once.





## Short Press Control Knob

While in communication mode, short press the Control Knob to enter the setup menu. The setup menu is used to adjust certain settings. The table below shows the different settings that can be adjusted. Below is a table of the settings that can be adjusted.

Press Control Knob	Setting control for:	LCD Display	How to adjust current setting:
1 time	Channel	Signal icon blinks	<ul style="list-style-type: none"> <li>• Turn the Control Knob until the desired channel is found.</li> <li>• Press the PTT button to exit.</li> </ul>
2 times	Talk Group	CTS icon blinks	<ul style="list-style-type: none"> <li>• Turn the Control Knob until the desired sub-channel is found.</li> <li>• Press the PTT button to exit.</li> </ul>
3 times	VOX	VOX icon blinks	<ul style="list-style-type: none"> <li>• Turn the Control Knob left or right to set the desired VOX sensitivity.</li> <li>• Press the PTT button to exit.</li> </ul>
5 times	Voice calling	Bluetooth® icon blinks	<ul style="list-style-type: none"> <li>• Turn the Control Knob to the right to enable voice calling.</li> <li>• Press the PTT button to exit.</li> </ul>
6 times			<ul style="list-style-type: none"> <li>• Complete settings.</li> <li>• Press the PTT button to exit.</li> </ul>
7 times			<ul style="list-style-type: none"> <li>• Return to the Communication mode.</li> </ul>

\* The X2Slim has a voice prompt that tells you what setting you are on.

## Multiple device modes

The X2Slim can operate on four different device modes. The table shown below will briefly explain those device modes.

	Device Modes	Description
A	Bike to Bike Group Communicator	Bike to bike communication is the primary device mode for the X2Slim user. It is also the default device mode when you turn the unit on. Unlimited number of riders can communicate as long as you are all on the same channel and talk group. With 22 channels and 38 talk groups for each channel, users can have 836 different possibilities of having their own communication path.
B	Rider to Passenger Communicator	Rider to passenger communication is also possible by sharing the X2Slim with a passenger headset (Passenger headset and extension cord sold separately). When in Intercom mode the communication with your passenger is private. When not in intercom mode, the passenger can also listen to the same audio device and/or music.





C	Bluetooth transmitter with Remote Control	The X2Slim built in Bluetooth® will allow you to wirelessly connect your Bluetooth® smartphone, MP3 player (w/BTA/BTD Bluetooth® adaptor), Bluetooth® ready GPS system, or Bluetooth® cell phone. * Depending on your device you can also remotely control your Bluetooth® ready devices with the X2Slim.
D	FM Radio	FM radio allows you to listen to local radio stations.

### 3. Bike to bike communication

The X2Slim can communicate with an unlimited number of riders. Before riding everyone must turn their units on and make sure they are on the same main channel and talk group. In order to transmit to other riders you must use the voice activation, handle bar mount PTT button, or the PTT on the unit. Once you talk, everyone on your channel will hear. However, only one person at a time can talk. It is a good idea to use the word "over" when done talking. This way others will know that they can now say something back. It is strongly suggested that you practice talking back and forth in your house before actually using on a ride. This way you can get a feel of what to expect.

#### Power On/Off

Press and hold the power button. You will notice that the LCD display will turn on. To power the unit off, press and hold the power button until you hear the beep.

#### Set volume level

Set the desired volume level by turning the Control Knob.

#### Choose a channel for the group

To be able to communicate with a group, all riders must be on the same channel and talk group. The instructions on how to set a channel and talk group can be found on the table below.

Press Control Knob	Mode selected:	Description of mode
1 time	Main Channel	<ul style="list-style-type: none"> <li>• Turn the Control Knob until the desired channel is found.</li> <li>• Press the Control Knob to set the channel.</li> <li>• Press the PTT button to exit the settings menu.</li> </ul>
2 times	Talk Group	<ul style="list-style-type: none"> <li>• Turn the Control Knob until the desired channel is found.</li> <li>• Press the Control Knob to set the channel.</li> <li>• Press the PTT button to exit the settings menu.</li> </ul>

Please keep in mind that main channels 8-15 are GMRS frequency as shown on the table below. If you want to have a maximum range of 5 miles you need to choose one of these. Main channels 1-7 and 16-22 operate on FRS (2 miles) frequencies. Use these channels if you want to communicate to FRS type radios.

Channel	Frequency	Maximum Range	Channel	Frequency	Maximum Range
1	FRS	2 miles	12	GMRS	5 miles





2	FRS	2 miles	13	GMRS	5 miles
3	FRS	2 miles	14	GMRS	5 miles
4	FRS	2 miles	15	GMRS	5 miles
5	FRS	2 miles	16	FRS	2 miles
6	FRS	2 miles	17	FRS	2 miles
7	FRS	2 miles	18	FRS	2 miles
8	GMRS	5 miles	19	FRS	2 miles
9	GMRS	5 miles	20	FRS	2 miles
10	GMRS	5 miles	21	FRS	2 miles
11	GMRS	5 miles	22	FRS	2 miles

Channel 10 is an Emergency Channel. Use the emergency channel only for the purpose of soliciting or rendering assistance to a traveler. This channel is also used by certain organizations during emergency situations and may not necessarily be monitored.

Side tone: When transmitting by using the PTT button and voice activation you will hear yourself in your own speakers. This is called a side tone. The side tone is what tells you that your microphone is working.

### Using the voice activation feature (VOX)

The voice activation feature is what allows you to communicate with other riders without using the PTT. This feature can work very well, but it does need patience and understanding. In order to activate VOX feature, press and hold the Control Knob until the unit beeps three times and the voice prompt says "VOX on". To adjust the VOX sensitivity, place the unit into Communication Mode. Then short press the Control Knob until the voice prompt says "VOX". Turn the Control Knob until the desired sensitivity is achieved. Setting 1 has the highest sensitivity. Setting 5 has the lowest sensitivity.

## 4. Rider to Passenger Communication

The X2Slim does not require a separate unit for a passenger to communicate with the rider and others. In order to connect with a passenger you must purchase an additional headset and extension cord. Please contact a dealer near you or call customer service.

### Listening to bike to bike communication

When connected, passenger cannot communicate with other riders.

### Rider and Passenger only communication

This unit allows a rider and a passenger to communicate in private without the need of an additional unit. You will need to purchase an additional pair of Chatterbox Universal Headsets and the Chatterbox extension cable. In order to activate this feature, double press the Control Knob, turn the Control Knob clockwise, and press the Control Knob to lock in the mode. This should open an open connection between rider and passenger for communication.





## 5. Bluetooth feature with audio control

The X2Slim is equipped with Bluetooth that allows you to pair up to 2 Bluetooth devices simultaneously. You must understand that NOT just ANY 2 Bluetooth devices will always work. When pairing two devices, Bluetooth only permits 1 hands free device and 1 audio device. You cannot pair 2 audio devices and you cannot pair 2 hands free devices. It will only allow 1 of each kind. An example of a hands free device is a cell phone. An example of an audio device is an iPod/MP3 player with a Bluetooth® adapter. Please note some Smart phones (iPhone and Android phones) take up BOTH devices when paired to the X2Slim. This is why you will be able to listen to music and answer the phone from a smart phone. These phones do not have an option to disable this. Some motorcycle specific GPS devices also take up both devices when paired. This is why you can listen to music, hear your voice prompted directions, and answer your phone through them.

\* You will find a chart below that explains the different combinations of accessories and what will work.

### Bluetooth® feature

The Bluetooth® feature will allow you to listen to the music, GPS direction, and/or answer phone calls wirelessly.

### Pairing

In order to pair the X2Slim to a Bluetooth® device you must follow the directions below. Please make sure that the device you are trying to pair is Bluetooth® capable.

1	Make sure the X2Slim is in the OFF position and the device you want to pair is near. Please note that you must make sure any other Bluetooth® devices in the area are turned off.
2	Press and hold the Control Knob and Power Button. You will hear a voice prompt say "Bluetooth® Pairing".
3	Follow the "pairing" instructions for you Bluetooth® device. Please allow about 30 seconds for your device to search X2Slim. If done correctly, you will notice the name "X2SLIM" on your devices Bluetooth® list.

### Pairing multiple devices

You can pair any Bluetooth® enabled MP3 player, Mobile phone, and Navigation system with X2Slim. However, only two devices can be paired with X2Slim simultaneously. Table shown below summarizes the way you can pair multiple devices simultaneously.

There are two ways you can get all three, music, navigation, and phone simultaneously.

The first way is by using a navigation system that supports pairing with mobile phone. This does NOT mean that any navigation system with Bluetooth® will work. These types of Navigation systems are usually the motorcycle specific models. (Garmin Zumo and Tom Tom Rider models) In this case, you need to pair your mobile phone to the Navigation system first then pair the navigation system and MP3 player to the X2Slim.

The second way is to buy one of the navigation apps for you Smartphone that supports In-app music player. With this route you can do the following all from your Smartphone; hear GPS voice prompted directions, answer phone calls, and listen to music from the Mp3 player. We highly recommend this setting.





	Bluetooth® enabled devices				Music	Navi- gation	Phone	
	Smart phone	Mobile phone	MP3 player	Navi- gation				

#### Ways to pair two devices

1					Yes		Yes	
2						Yes	Yes	
3					Yes	Yes		

#### Ways to pair three devices

4					Yes	Yes	*Yes	*Navigation system that supports pairing with phone: TomTom rider2, Zumo550
---	---	---	--	---	-----	-----	------	---

#### Smart way to get music, navigation, and phone simultaneously by pairing one device

5					Yes	Yes	*Yes	*You need to buy GPS apps for your Smartphone that supports In-App Music player (Gokivo, TomTom)
---	---	--	--	--	-----	-----	------	--

### Using Smartphone to get music, phone, and navigation

Once you have paired your Smartphone with X2Slim, you may listen to your music from your Smartphone using your own playlist. When there's an incoming phone call, you will hear your music fade away and a ringtone will play. You simply short press the Control Knob on X2Slim to answer. If you want to end the call, just short press the Control Knob again. As soon as you end the call, the music will continue to play.

If you want to use a navigation system, you will need to buy one of the navigation apps offered for your Smartphone. Please make sure you get the In-App music player for a more streamlined operation. Unlike the navigation system that relies on a network to get the maps and information, there are systems that can be used during the absence of a network by accessing the maps and information already downloaded in your Smartphone. If you phone has enough disk space, this option is the most suitable for the motorcycle riders.

\*For longer rides that rely on a phone's navigation system, you will need to have a charger for your Smartphone. Chatterbox offers a USB power cord and Tank Bag for this purpose.





## Remote control

The X2Slim Bluetooth® feature can also remotely control the devices so that you don't have to reach for your device in your pocket dangerously while you are riding. The Table below will show you the remote control functions available. (Does not apply to all devices)

\*Long press: Hold the button for 3 seconds, Short press: hold the button for half second)

	Music	GPS	Phone	Buttons to use (Only in Bluetooth® mode)
Pause and Play	Yes			Short Press the Control Knob
Skip track	Yes			Turn the Control Knob to the left while pressing the Control Knob
Reverse track	Yes			Turn the Control Knob to the right while pressing the Control Knob
Volume Up & Down	Yes	Yes	Yes	Turn the Control Knob
Answer incoming call			Yes	Short press the Control Knob
End incoming call			Yes	Short press the Control Knob

You must be in Music Playing Mode for music playback.

## 6. FM Radio

The X2Slim has a built in FM radio player. The following will explain how to use the FM radio feature.

### Turn on/off the FM Radio

After the X2Slim is on, press the Control Knob twice. Turn the Control Knob until the unit is on FM mode.

### Change volume

While listening to the radio, turn the Control Knob left (down) or right (up) to adjust the volume.

### Search FM radio stations

While listening to the radio, short press the Control Knob. Then turn the Control Knob left or right to find the desired station.

## 7. Putting it all together

### Typical setting

The most typical setting for the X2Slim is listening to your music, hearing voice prompted direction from your navigation system, and answering incoming calls while you communicate with your fellow riders and/or passenger.

1	Turn on X2Slim.
2	Choose and set the channel and talk group. Test with the PTT button or VOX to see if everyone can hear each other.





3	Pair your smartphone with navigation app to the X2Slim.
4	Set the X2Slim to Music Playing Mode.
5	Now you should be able to listen to music and hear the turn by turn directions from your navigation system. You can also answer your phone calls by short pressing the Control Knob.
6	Finally, you can communicate with other riders who are on the same channel.

### Priority

The table shown below summarizes the priority among different devices. When you are on the Bluetooth® device mode, the navigation directions and phone calls get priority over the music. This means that when a phone call is answered the music will be paused. As soon as the call ends, the music will play again. Same thing applies with fellow rider communication. When you hear communication the music will pause. After the communication is finished the music will automatically come back.

Priority	1	2	3	4
Bluetooth®	Cell phone	Rider Communication	Navigation	MP3
FM Radio	Cell phone	Rider Communication	FM Radio	

### Summary of button functions

The table below will summarize the button functions that have been explained in this manual.

	Rider Communication (Any Setting)	Rider to Passenger communication (Private)	Bluetooth® Feature	FM Radio
To Activate	Turn unit on	Enter Intercom mode	Always On*	Enter Fm Mode
To Deactivate	Turn unit off	Exit Intercom mode	Turn unit off	Exit Fm Mode
Volume Up	Turn Control Knob clockwise	Turn Control Knob clockwise		Turn Control Knob clockwise
Volume Down	Turn Control Knob counter clockwise	Turn Control Knob counter clockwise		Turn Control Knob counter clockwise
To Talk	Press and hold PTT or use VOX			
To Answer Phone Call	Press Control Knob		Press Control Knob	Press Control Knob
To reject Phone Call	Long press Control Knob	Long press Control Knob	Long press Control Knob	Long press Control Knob
To skip music track or radio station			Press and turn Control Knob counter clockwise	Press and turn Control Knob counter clockwise












To reverse music track or radio station			Press and turn Control Knob clockwise	Press and turn Control Knob clockwise
To pause and play			Press Control Knob	

\* For first time pairing to a new device, press and hold power button and Control Knob simultaneously until unit enters pairing mode.

## 8. Accessories

1		Replacement USB charging cable and AC adaptor
2		Replacement Headset with microphones for open and full face helmet, two Velcro disks, sponge, wooden wire tuck stick, and Velcro set for microphones
3		PTTB and extension cord
4		Mounting bracket with Cradle, two screws, Allen ranch
5		Headset Extension cord
6		Power filter cord
7		Sponge and Velcro Kit (5 pieces of microphone sponge, 5 pairs of speaker Velcro, and 5 pairs of microphone Velcro for full face helmet)







## 9. Trouble shooting

Questions	Answers
While using voice activation the transmission is being cut out while trying to communicate to other riders	Position the microphones directly kissing your lips and speak without pausing. The closer the microphones is to your lips, the clearer you can transmit.
I don't hear group communication	Adjust the microphones sensitivity to a lower setting (counter clockwise)
Transmission range is a lot shorter than it is claimed	Make sure you are clear of power lines foliage, hills, and buildings. Those obstacles will reduce the maximum transmission range. Even weather makes a difference.
I can hear too much surrounding noise while hearing the transmission from other group members	Add foam or cotton directly to the tip of the microphones and place the wind sock over it.
I can not listen to music from my Bluetooth® enabled MP3 player after I paired it with X2Slim	Allow up to 30 seconds for the devices to pair and the music should automatically start playing through the headset. If this does not occur after 30 seconds, turn off the unit and follow the steps again from the beginning.

## 10. Important information

### Chatterbox USA Limited Warranty

Chatterbox USA guarantees that each new Chatterbox will be free from defective materials and workmanship for a period of one (1) year from the date of original purchase. Chatterbox will remedy any such defect by repair or replacement (at our discretion) of the products, provided they are delivered to the address listed below, intact for examination, with all transportation charges prepaid and accompanied by a copy of the original retail sales receipt. The provisions of this warranty shall not apply to any unit which has been subject to misuse, neglect, incorrect installation, unauthorized modification, accident, or has been repaired or altered outside of our factory. The express warranty contained herein is in lieu of all other warranties, expressed, implied or statutory, including without limitation any warranty of merchantability or fitness for a particular use. In no event will Chatterbox be liable to the buyer for any damages, including special, incidental, indirect, or consequential.

### FCC Compliance

This device has been tested and found to comply with the limits for a class b digital device pursuant to part 15 of the FCC rules. The operation is subject to the following two conditions;

- (1) This device may not cause harmful interference
- (2) This device must accept any interference received including interference that may cause undesired operation.

\* Any changes or modifications not expressly approved by the parties responsible for compliance could void the users' authority to operate this device





## US Motorcycle Laws by States

Certain states and localities may prohibit the use of two earpieces or two-piece headsets while operating a vehicle. Please check and follow all applicable federal, state, and local laws and regulations regarding the use of electronics, earpieces and headsets before operating your vehicle.

This link shown below is provided for informational purpose only. We do not guarantee the accuracy of the information. Please verify the accuracy of the information before use.


<http://www.americanmotorcyclist.com/asp/legisltn/laws.asp>

## Technical Specification

GENERAL	
Frequency range	From 462.550 MHz to 467.7125 MHz
Modulation type	8KOF3E (FM)
Channel capacity	22 Channels
Channel spacing	12.5KHz
Power supply pack	DC 3.7 V; Li-ion rechargeable
Current drain transmitter	(1W); <1000mA
Battery life	8 hours talk time , 20 hours of stand by time
Operating temperature	-20C + 60C
Dimensions	51(H) x 99 (W) x 21 (D) mm
Weight	3.2 oz. (with battery)
TRANSMITTER	
Power output	FRS 0.5W/GMRS 1.0W
Frequency stability	Better than +/- 5ppm within
Hum & Noise	-40dBc (with 300Hz to 3KHz audio filter)
Spurious & Harmonics	-60dBc
Audio distortion	less than 5% (1KHz tone 60% modulation)
RECEIVER	
Sensitivity (12dB SINAD)	0.2uV (-119dBm SINAD)
Selectivity	-60dB
Inter-Modulation	-60dB
Spurious and image	-60dB rejection
Maximum audio output	more than 100mW
Audio distortion	less than 5%
Hum & Noise	-40dBc (with 300Hz to 3KHz audio filter)



## X2Slim Wireless PTT (for -p model only)



Powering ON wireless PTT button: Press and hold POWER button for 2-3 seconds until Blue LED light illuminates.

Powering OFF wireless PTT button: Press and hold POWER button for 2-3 seconds until Red LED light illuminates.

### Instructions for pairing wireless PTT to X2Slim

1. Place PTT button in pairing mode: From the OFF position, push and hold the POWER button until the Blue LED flashes rapidly.
2. Place X2Slim in PTT pairing mode: From the OFF position, push and hold PTT button while turning on the unit. The voice prompt will say Bluetooth® pairing. The X2Slim is now in PTT pairing mode.
3. Allow 5-10 seconds for X2Slim and PTT to pair. When X2Slim and PTT button are successfully paired, the Blue LED on the PTT button and X2Slim will blink.
4. Display "SCN" on the top of the LCD screen.

\* From this point forward both the PTT button and X2Slim will automatically pair when turned on. You must always turn the X2Slim on first before turning on the Wireless PTT button.



**Chatter** **Box!**™

16310 Arthur Street, Cerritos, CA 90703  
[www.chatterboxusa.com](http://www.chatterboxusa.com)  
Customer Service: 888-452-2269  
[info@chatterboxusa.com](mailto:info@chatterboxusa.com)

Congratulation on your purchase of the Chatterbox product.  
For additional information, go to [chatterboxusa.com](http://chatterboxusa.com)

For product support, go to  
[www.chatterboxusa.com/support](http://www.chatterboxusa.com/support)